

ARMANOV


Ball Bearing Roller handle for
Dillon XL650, XL750, RL550 and
Hornady Lock-and-Load AP, Iron

Installation Instructions




Armanov d.o.o.
Brezovce 9
1236 Trzin, Slovenija
Tel: +386 30 467 000
armanov.com


①



② Un-screw the original ball from handle



- ③** Tighten up strongly and apply thread-lock



- ④** Adjust your handle to position

